

# OPERATOR'S MANUAL

TH644C TH842C TH844C

#### **■ TEREX HANDLERS**

455 N. Superior Ave. Baraga, MI 49908-0790 Ph. (906) 353-6675 Fax (906) 353-7543 http://www.terexlift.com



# TABLE OF CONTENTS

SECTION 1	ROUGH TERRAIN FORK LIFT SAFETY SECTION	1-1
	Introduction	1-3
	Standards And Symbols	1-4
	Safety	1-5
	Training And Knowledge	1-5
	Operator's Responsibilities	1-6
	Management's Responsibilities	1-7
	Maintenance And Repair	1-8
	Operation Safety	1-9
SECTION 2	GENERAL SAFETY	2-1
	General Safety Procedures	2-3
	Jump Starting	2-8
	Proper Load Chart Use	2-9
SECTION 3	CONTROLS AND INSTRUMENTS	3-1
	Operator's Compartment	3-3
	Joystick Control Functions	3-4
	Joystick Control Functions (Button Pushed)	3-5
	Service Brakes	3-6
	Low Service Brake Pressure Light	3-6
	Parking Brake	3-7
	Frame Sway Control	3-8
	Gauges	3-9
	Hydraulic Pump Destroke Button	3-9
	Steering Steering	3-10
	Transmission	3-10
	Front Axle Differential Lock	3-10
SECTION 4	<b>OPERATION</b>	4-1
SECTION	Operation And Safety Guidelines	4-3
	Before Starting The Engine	4-4
	Starting The Engine	4-9
	Before Operating The Forklift	4-11
	Transporting A Load	4-15
	Placing A Load	4-17
SECTION 5	MAINTENANCE PROCEDURES	5-1
DECTION	General Safety Practices	5-3
	Service Intervals	5-5
	Required Grease Intervals	5-6
	Grease Fitting Locations	5-7
	Daily Maintenance Procedures	5-8
	50 Hour Maintenance Procedures	5-12
	100 Hour Maintenance Procedures	5-15
	250 Hour Maintenance Procedures	5-17
	500 Hour Maintenance Procedures	5-18
	750 Hour Maintenance Procedures	5-20
	1000 Hour Maintenance Procedures	5-21
	2000 Hour Maintenance Procedures	5-23
	Filter Guide	5-24
	Recommended Fluids And Capacities	5-24
	Hydraulic Pressure Settings	5-25
SECTION 6	MATERIAL SAFETY DATA	6-1
	Material Safety Data Sheets	6-3
	https://www.forkliffodfmanuals.com/	6-4



# **SECTION 1**

# ROUGH TERRAIN FORK LIFT SAFETY

# TABLE OF CONTENTS

## SECTION 1 - ROUGH TERRAIN FORK LIFT SAFETY

Introduction	1-3
Standards And Symbols	1-4
Safety	1-5
Training And Knowledge	1-5
Operator's Responsibilities	1-6
Management's Responsibilities	1-7
Maintenance And Repair	1-8
Operation Safety	1.0

# **A ROUGH TERRAIN FORK LIFT SAFETY**

#### INTRODUCTION

Owners, Users, and Operators:

Terex (Handlers) appreciates your choice of our machine for your application. Our number one priority is user safety, which is best achieved by our joint efforts. We feel that you make a major contribution to safety if you, as the equipment users and operators:

- Comply with OSHA, Federal, State, and Local Regulations.
- Read, Understand, and Follow the instructions in this and other manuals supplied with this machine.
- Use Good Safe Work Practices in a common sense way.
- Only have trained/certified operators directed by informed and knowledgeable supervision – running the machine.

**NOTE:** OSHA prohibits the alteration or modification of this machine without written manufacturer's approval. Use only factory approved parts to service or repair this machine.

If there is anything in this manual that is not clear or which you believe should be added, please send your comments to the Manager of Publications, *Terex Handlers*, *P.O. Box 790*, *Baraga*, *Michigan 49908*. *Telephone number 906-353-6675*.

Thank you!



THIS SYMBOL MEANS YOUR SAFETY IS INVOLVED! READ, UNDERSTAND AND FOLLOW ALL DANGER, WARNING AND CAUTION DECALS ON YOUR ROUGH TERRAIN FORKLIFT.

# **AROUGH TERRAIN FORK LIFT SAFETYA**

#### STANDARDS AND SYMBOLS

## **STANDARDS**

Many aspects of rough terrain forklift operation and testing are discussed in standards published by the American National Standards Institute. These Standards are updated on a regular basis with addendas. Terex recommends that you purchase and refer to the following standards.

ANSI B56.6 - Rough Terrain Fork Lifts

This Standard can be purchased from:

American National Standards Institute 25 West 43nd Street, 4th Fl. New York, New York, 10036 Tel. 212.642.4900 Fax. 212.398.0023

## **SYMBOLS**

The symbols below are used to inform the operator of important information concerning the operation of this machine.



DANGER – Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING – Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION – Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



ATTENTION – Indicates a situation which, if not avoided, may result in property or equipment damage.

# **A ROUGH TERRAIN FORK LIFT SAFETY**

#### SAFETY





These are general safety rules, which must be followed. You are also required to read and understand the Operator's Manual as there are instructions, which are more detailed specific to this machine.

#### TRAINING AND KNOWLEDGE

- Safety must always be the operator's most important concern.
- This machine must only be operated by trained personnel, who have demonstrated their ability to do so safely.
- Comply with the requirements of current Occupational Safety and Health Administration (OSHA) standards, including 29CFR1910.178; and the American National Standards Institute (ANSI) B56.6 latest edition.
- Read and Understand all Decals and Warnings.
- Read and Understand the Rating Chart.
- Know that the machine can safety lift each load before attempting to lift.

# **AROUGH TERRAIN FORK LIFT SAFETY**

## OPERATOR'S RESPONSIBILITIES

- Read and understand the Operator's Manual.
- Know the location and the purpose of the controls, instruments and indicator lights.
- Make sure the machine is in proper order and all operational aids and warning signals are functional before operating.
- Keep the machine clean, including all instrumentation, windows, lights and other glazed surfaces.
- Use protective clothing and safety equipment. Always use approved safety equipment such as: gloves, safety boots, hard hats, safety glasses and ear protection where necessary.
- Wear protective clothing that is snug and belted where required.
- Store tools and other necessary items in the toolbox.
- Never lift a load without a Load Rating Chart in the cab.
- Know the load to be lifted.
- 10. Be alert, physically fit and free from the influences of alcohol, drugs or medications that might affect the operator's eyesight, hearing, or reactions.
- Keep people, equipment and material out of the work area.
- Keep a fully charged fire extinguisher and first aid kit in the cab at all times, and be familiar with how to use these items.
- Know about movements of other machinery, trucks and personnel at the jobsite.
- 14. Make sure everyone is in a safe place before moving the boom, forks, load or outriggers (if so equipped.)
- Start and stop movements smoothly and swing at speeds that will keep the load under control.

# **⚠ROUGH TERRAIN FORK LIFT SAFETY⚠**

## MANAGEMENT'S RESPONSIBILITIES

- 1. Ensure operators are competent, physically fit, trained and if required licensed.
- 2. Have a supervisor at the job site to be responsible for job safety.
- Crew members given specific safety responsibilities and instructed to report any unsafe conditions to the supervisor.
- 4. Supply the weight on the load to be lifted to the operator.
- Verify that all crewmembers are familiar with OSHA, ANSI B56.6 requirements as well as instructions in the manuals.

# **⚠ ROUGH TERRAIN FORK LIFT SAFETY⚠**

#### MAINTENANCE AND REPAIR

- Practice safe maintenance procedures. Perform all maintenance and repairs in accordance with instructions provided by the manufacturer in the manuals. Also heed the warnings on the placards and decals on the machine.
- Always use supports and braces when working on, under or around the machine or forks.
- Shut off the engine and lockout the machine while working on the machine unless instructions specifically require the engine to be running.
- Always make sure the machine is stationary prior to performing adjustments or lubrication.
- Replace all shields and guards after performing service.
- 6. Always use a piece of cardboard or paper to search for leaks.
- When performing work on the hydraulic system:
  - i. Lower the boom to horizontal.
  - ii. Support the boom with supports or braces.
  - iii. Shut down the engine.
  - iv. Relieve all pressure before disconnecting lines.
  - Ensure all connections are tight before applying pressure.
  - Repair or replace any damaged line, hose or fitting before applying pressure.
- Always have tires serviced and mounted by a qualified person with the proper tools and guards.
- Always use an inflation cage during tire inflation.
- Only perform welding on the machine with approval from the manufacturer.

# **A ROUGH TERRAIN FORK LIFT SAFETY**

#### OPERATION SAFETY

- Always inspect the machine daily. Check for leaks, worn hoses, loose belts, broken structures, and loose or missing bolts. Repair or replace any worn, damaged or leaking parts prior to operation of the machine.
- 2. Only inspect the coolant level when the engine and coolant are cool.
- 3. Be sure that all guards and screens are secure and in the proper place.
- Inspect for and clear the work area of any obstructions that could interfere with proper machine operation. Any obstructions that cannot be cleared should be clearly marked and avoided during operation.
- 5. Refueling:
- i. Always stop the engine before refueling the machine.
- ii. Fill the fuel tank outdoors.
- Handle fuel with care, as it is highly flammable. Do not refuel the machine while smoking or near open flames.
- iv. Always clean up spilled fuel.
- Make sure the machine and access system is clean and free of dirt, oil, grease or debris.
- When getting on and off the machine, face the machine, use the steps and handrails provided, and always maintain a three point contact.
- Always remain completely inside the cab enclosure while operating the machine.
- Always wear the seat belt while operating the machine.
- Always completely lower the boom with the forks resting on the ground before any work is performed on or around the machine.
- 11. Do not operate the machine while people are under or near an elevated boom whether the boom is loaded or unloaded. Falling objects from the forks or attachment may cause serious injury or death.

# **AROUGH TERRAIN FORK LIFT SAFETY**

#### OPERATION SAFETY

 Maintain an appropriate clearance from electrical power lines. See the chart below for minimum safe approach distances.

Minimum Safe Approach Distance				
Power Line Voltage	Required Clearance			
0 to 50 kV	10 ft. (3.00 m)			
50 to 200 kV	15 ft. (4.60 m)			
200 to 350 kV	20 ft. (6.10 m)			
350 to 500 kV	25 ft. (7.62 m)			
500 to 750 kV	35 ft. (10.67 m)			
750 to 1000 kV	45 ft. (13.72 m)			

#### 13. Lifting Loads:

- Using the load chart, confirm that the load is within the rated capacity of the machine for the required configuration.
- ii. Level the machine using the level gauge before lifting loads. Use the sway control to level the machine only when the boom is at horizontal or lower. Using the sway control with the boom above horizontal may cause the machine to overturn.
- Verify that the load is secured on the forks before performing a lift.
   Rearrange the load if necessary.
- Before lowering a maximum load, always retract the boom completely.
- Use proper attachments, such as a truss boom, to lift suspended loads.
- 14. If the load to be lifted exceeds the capacity of the machine for the given configuration:
  - Move the machine closer to the load so that the weight of the load will be within the allowable load chart specifications.
  - ii. Divide the load into smaller pieces.
  - Get a larger machine capable of handling the load.
- 15. Always move a load so that you have maximum machine stability and visibility is not obstructed. Keep the boom at or below horizontal, with the load close to the ground.
- Tilt the forks back towards the machine slightly during travel to ensure stability of the load.

# **ROUGH TERRAIN FORK LIFT SAFETY**

#### OPERATION SAFETY

- 17. Inspect the path of travel before beginning movement. Avoid holes and dropoffs.
- Traveling on slopes/grades.
  - i. Ascend and descend slowly and with caution.
  - ii. When loaded, always travel with the load uphill.
  - iii. When unloaded, travel with the attachment downhill.
  - iv. Avoid turning, travel straight up and down.
- Always position all wheels in line with the machine before switching the steering mode.
- 20. Always position the machine and set the park brake before lifting a load.
- 21. Do not allow riders on the machine or forks.
- 22. Do not transport or lift personnel into position with this forklift.
- 23. When leaving the operator's station:
  - i. Place the directional controls in neutral.
  - ii. Apply the parking brake.
  - iii. Lower the attachment to the ground.



# SECTION 2 GENERAL SAFETY

# TABLE OF CONTENTS

## SECTION 2 - GENERAL SAFETY

General Safety Procedures	2-3
Jump Starting	2-8
Proper Load Chart Use	2-9

# **⚠** GENERAL SAFETY **⚠**

#### GENERAL SAFETY PROCEDURES

#### SAFETY ALERT SYMBOL

Stop and take time to read ALL safety alert messages. Follow all safety messages to avoid injury and/or death.



ALWAYS wear eye protection and personal safety equipment.

#### THE OPERATOR

The operator must be fully trained and qualified to operate this machine.

Before start-up or machine operation, the operator must learn the location and purpose of the:


- 1. Controls
- 2. Instruments
- 3. Indicator lights
- 4. Safety and instruction labels

#### ACCIDENT PREVENTION

Use protective clothing and safety equipment. Always use approved safety equipment such as: gloves, safety boots, safety hard hats, goggles and ear protection when necessary.

Wear protective clothing that is snug and belted where required.








#### FIRE PREVENTION/FIRST AID

Install a first-aid kit and fire extinguisher in the operator's cab.

KEEP THE FIRST-AID KIT and FIRE EXTINGUISHER properly maintained. Follow the instructions provided with the first-aid kit and fire extinguisher.





# GENERAL SAFETY

#### GENERAL SAFETY PROCEDURES

#### WELDING PRECAUTIONS



## CAUTION

Any unauthorized welding can cause structural failure or possible personal injury. **DO NOT** weld on any structural member. All unauthorized welding will void the warranty.



#### HAND HOLDS AND STEPS



## WARNING

Slips and falls can cause serious injury.

When getting on and off the machine, always maintain a three point contact with steps and hand rails while facing the machine.

DO NOT use the steering wheel or any other controls as handrails.

NEVER jump on or off the machine.

Be careful of slippery conditions on platforms, steps and handrails when getting on and off the machine.

ALWAYS shut off the engine before leaving the operator's station.



#### REFUELING



## WARNING

Fires can cause death or severe personal injury.

Handle fuel with care. It is highly flammable. **DO NOT** refuel the machine while smoking or when near open flames or sparks.

ALWAYS stop the engine before refueling the machine. Fill the fuel tank outdoors.

Prevent fires by keeping the machine clean of trash, grease and debris. ALWAYS clean up spilled fuel.



# GENERAL SAFETY A

#### GENERAL SAFETY PROCEDURES

#### HYDRAULIC SAFETY




## WARNING

Hot hydraulic oil can cause severe burns. DO NOT work on the hydraulic system if the oil temperature exceeds 120 degrees F. (49 degrees C).

Before ANYONE works on the hydraulic system:

- 1. Lower the boom to the horizontal position.
- Support the boom to avoid unintentional lowering.
- 3. Shutdown the engine.
- 4. Remove the key from the ignition.
- 5. Clean the area around the oil reservoir cap (A).



#### FLUIDS UNDER PRESSURE




## !\ WARNING

Escaping fluid under pressure can penetrate the skin and can cause serious personal injury.

Use a piece of cardboard or paper to search for leaks. DO NOT use hands. Before disconnecting hydraulic lines, be sure to relieve all line pressure. Before applying pressure to the system, be sure that all connections are tight. DO NOT apply pressure to a damaged line, hose or fitting.

If injured by escaping fluid, see a doctor at once. Proper medical treatment must be administered immediately. A serious infection or reaction can result without proper medical treatment.




#### SERVICE TIRES SAFELY



#### WARNING

An improperly mounted over-pressurized tire can result in tire explosion causing possible personal injury. An inflation cage or other safety device must be used during tire inflation.

DO NOT attempt to mount a tire unless you have the proper equipment and experience to perform the job. If you do not have the proper qualifications to perform the job have your dealer or qualified repair service perform the repair.





# **GENERAL SAFETY**



#### GENERAL SAFETY PROCEDURES



## CAUTION

#### USE SEAT BELT

Always wear the seat belt while operating the machine to reduce the risk of personal injury.



## CAUTION

#### PRACTICE SAFE MAINTENANCE

Unauthorized modifications to the machine may impair the safety, machine function and/or affect machine life.

ALWAYS use a safety support or brace when working on, under, or around the machine or forks.

DO NOT adjust or lubricate the machine while it is in motion.

SHUT OFF the engine and LOCKOUT the ignition while working on the machine unless maintenance instructions require the engine to be running.

REPLACE all the shields and guards after servicing.

NEVER use the machine as a platform for lifting personnel.



## CAUTION

#### **BOOM SAFETY**


**DO NOT** enter the **DANGER AREA** under or around the boom when the forks are off the ground or while the engine is running. (See diagram at right for **DANGER AREA**).


Serious personal injury could result if the boom should unexpectedly drop.

Before ANY work is performed in the DANGER AREA the boom must be COMPLETELY lowered and the forks must be resting on the ground.

https://www.forkliftpdfmanuals.com/







# **⚠** GENERAL SAFETY **⚠**

#### GENERAL SAFETY PROCEDURES

#### AVOID ELECTRICAL POWER LINES



REQUIRED CLEARANCE FOR NORMAL VOLTAGE IN OPERATION NEAR HIGH VOLTAGE POWER LINES AND OPERATION IN TRANSIT WITH NO LOAD AND BOOM OR MAST LOWERED.

Normal Voltage, kV	Minimum Required
(Phase to Phase)	Clearance, ft. (m)
Operation Near High Voltage Power	Lines
to 50	10(3.05)
Over 50 to 200	15 (4.60)
Over 200 to 350	20 (6.10)
Over 350 to 500	25 (7.62)
Over 500 to 750	35 (10.67)
Over 750 to 1000	45 (13.72)
Operation in Transit With No Load a	and Boom Lowered
to 0.75	4(1.22)
Over 0.75 to 50	6((1.83)
Over 50 to 345	10(3.05)
Over 345 to 750	16 (4.87)
Over 750 to 1000	20 (6.10)
	- 110

# ⚠ v


## WARNING

Always remain completely inside the cab enclosure while operating the machine.



## WARNING


Never operate this machine under the influence of drugs, alcohol and/or medication which can cause drowsiness.



# <u>^</u>!\,

#### WARNING

Never transport or lift personnel into position with this forklift. It is not designed as a personnel lifting device.





# GENERAL SAFETY



#### JUMP STARTING

Location: The battery is located under the fuel tank / battery box cover (A).

#### JUMP STARTING

Jump starting at the battery or battery replacement is required when the battery is discharged to the point where the battery will not crank the starter.



Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.

Batteries also contain other chemicals known to the State of California to cause cancer.

Wash hands after handling.




Never jump start the machine directly to the starter or the starter solenoid. Serious injury or death could result from the machine moving forward or backward.

# **WARNING**

To avoid personal injury when jump starting with another machine, be certain that the machines are not touching. Never jump start a frozen battery as it will explode. Keep sparks and flames away from the battery. Lead acid batteries generate explosive gases when charging. Wear safety glasses when working near batteries.

The booster battery must be a 12 volt type. The machine used for jump starting must have a negative ground electrical system. To jump start the machine, proceed as follows:

- Connect the positive (+) jumper cable to the positive (+) post of the discharged battery.
- Connect the other end of the same jumper cable to the positive (+) post of the booster battery.
- Connect one end of the second jumper cable to the negative (-) post of the booster battery.
- Make the final cable connection to the engine block or the furthest ground point away from the battery.
- 5. Start the engine.
- Remove the jumper cables in the reverse order of their connection (i.e. negative cable ground connection first, etc.)






#### PROPER LOAD CHART USE

# **N**WARNING

NEVER raise a load and drive to position it. This can cause the machine to turnover. When placing a load, always move a loaded machine with the boom angle indicator (B) at 0 degrees or less. When the machine is as close as possible to where the load needs to be placed, set the parking brake, raise the load, then place the load into position.

The load chart shows the operating limits of a properly maintained and operated machine. To use the load chart the operator must know the weight of the load and how far "out" and "up" it is to be placed. If the load is heavier than stated on the load chart, three options can be used:

- Move the machine closer to the load so that the weight of the load will fall within the load chart specifications.
- Divide the load into smaller pieces so that each piece falls into load chart specifications.
- Get a larger machine capable of handling the load within specifications.





# GENERAL SAFETY !



#### PROPER LOAD CHART USE

#### TH644C

#### TEREX HANDLERS

P.O. BOX 790 455 NORTH SUPERIOR AVENUE BARAGA, MICHIGAN 49908 PHONE 906-353-6675 FAX 906-353-7543


MANUFACTURER'S RECOMMENDED CAPACITY IS PER ANSI B56.6 STABILITY TESTS USING STANDARD HOMOGENEOUS CUBES 4x4x4 FT. (1,22x1,22x1,22 METERS), LOAD CAPACITIES AT 24 INCH (.61 METERS) LOAD CENTER WITH STANDARD FORK FRAME. RATED LIFT CAPACITIES SHOWN ARE WITH MACHINE ON A FIRM, LEVEL SURFACE WITH UNDAMAGED, PROPERLY INFLATED TIRES.

LOAD LIMITS / HORIZONTAL BOOM LAST FULLY VISIBLE LETTER

RETRACTED = 6,000 LBS

(A) LETTER VISIBLE = 4,000 LBS (B) LETTER VISIBLE = 3,000 LBS (C) LETTER VISIBLE = 2,000 LBS

P/N 2-1274



#### TH842C

#### TEREX HANDLERS

P.O. BOX 790 455 NORTH SUPERIOR AMENUE BARACA, MICHIGAN 49908 PHONE 908-353-6675 FAX 905-353-7543

MANUFACTURER'S RECOMMENDED CAPACITY IS PER ANSI 856.6 STABBUTY TESTS USING STANDARD HOWOGENEOUS CUBES 4x4v4 FT. (1.22x1.22x1.22 METERS) LOAD CAPACITIES AT 24 INCH (81 METERS) LOAD CENTER WITH STANDARD FORK FRAME.

RATED LIFT CAPACITIES ARE WITH :

MACHINE ON A FIRM, LEVEL SUBFACE WITH UNDAWAGED, PROPERLY INFLATED CALCIUM CHLORIDE SOLUTION FILLED TIRES OR OPTIONAL FOAM FILLED TIRES, REAR AXLE LOCK-UP ENGAGED.

LOAD LIMITS / HORIZONTAL BOOM LAST FULLY VISIBLE LETTER

RETRACTED = 8,000 LBS


(A) LETTER WISBLE = 4,000 LBS

(B) LETTER WISBLE = 4,000 LBS

(C) LETTER WISBLE = 2,000 LBS

(D) LETTER WISBLE = 2,000 LBS

P/N 3-1483





#### PROPER LOAD CHART USE

## **TH844C**

#### TEREX HANDLERS

P.O. BOX 790 455 NORTH SUPERIOR AVENUE BARADA, MCS-100-6676 PHONE 905-353-6676 FAX 805-353-7543


MANUFACTURER'S RECONNENDED CAPACITY IS PER ANSI 856.6 STABILITY TESTS USING STANDARD HOMOCENEOUS CUBES AVAILATED TO THE STANDARD CAPACITIES AT 24 INCH (.61 METERS) LOAD CONTER WITH STANDARD FORK FRAME.

#### RATED LIFT CAPACITIES ARE WITH ...

MACHINE ON A FRM. LEVEL SURFACE WITH UNDAMAGED, PROPERLY INFLATED CALCIUM CHLORDE SOLUTION FILLED TIRES OR OPTIONAL FORM FILLED TIRES. REAR AXLE LOCK-UP ENGAGED.

LOAD DMITS / HORIZONTAL BOOM
LAST FULLY WSIBLE LETTER
RETRACTED = 8,800 LBS
(A) LETTER VISIBLE = 6,000 LBS
(B) LETTER VISIBLE = 4,000 LBS
(C) LETTER VISIBLE = 3,000 LBS
(D) LETTER VISIBLE = 2,000 LBS

P/N 2-1286





# SECTION 3 CONTROLS AND INSTRUMENTS

# TABLE OF CONTENTS

## SECTION 3 - CONTROLS AND INSTRUMENTS

Operator's Compartment	3-3
Joystick Control Functions	3-4
Joystick Control Functions (Button Pushed)	3-5
Service Brakes	3-6
Low Service Brake Pressure Light	3-6
Parking Brake	3-7
Frame Sway Control	3-8
Gauges	3-9
Hydraulic Pump Destroke Button	3-9
Steering	3-10
Transmission	3-10
Front Axle Differential Lock	3-11


#### OPERATOR'S COMPARTMENT

- Accelerator Pedal
- 2. Joystick 4-way Controller
- 3. Transmission Control Lever
- 4. Steering Selector
- 5. Service Brake Pedal
- 6. Rear Wiper Switch
- 7. Load Chart

- 8. Hourmeter
- 9. Gauges
- 10. Machine Level Gauge
- 11. Plug / 12 Volt Access.
- 12. Seat
- 13. Frame Level Switch
- 14. Seat Belt


- 15. Parking Brake Switch
- 16. Pump Off Button
- 17. Front Wiper Switch
- 18. Ignition Switch
- 19. Auxiliary Hydraulics
- 20. Steering Wheel
- 21. Headlight Switch


- 22. Heater Switch
- 23. Plug / Turn Signal Wires
- 24. Interior Rear View Mirror
- 25. Frt.Axle Differential Lock
- 26. Low Brake Press. Light
- 27. Work Lights Switch




## JOYSTICK CONTROL FUNCTIONS












- C Boom Out
- D Boom In







- E Boom Down and Out
- F Boom Up and In
- G Boom Up and Out
- H Boom Down and In




## JOYSTICK CONTROL FUNCTIONS (BUTTON PUSHED)





#### SERVICE BRAKES




## LOW SERVICE BRAKE PRESSURE LIGHT




#### WARNING

Insufficient hydraulic pressure to the service brakes may result in increased stopping distances causing possible injury or death and/or damage to the machine or property.

The illumination of the "LOW BRAKE PRESSURE" light (B) when the machine is running indicates this potentially hazardous condition. Should this condition ever exist, discontinue
use of the machine immediately. Contact a qualified service
technician to resolve this problem.






## PARKING BRAKE



Failure to set the parking brake before leaving the machine may result in unintended machine movement and possible injury or death and/or damage to the machine or property.

The parking brake should be engaged anytime the operator gets off the machine. To engage the parking brake, toggle the parking brake switch (C) forward. The red light in the upper part of the parking brake switch should illuminate.





#### FRAME SWAY CONTROL


# **WARNING**


Always ensure that the machine level indicator (B) is at zero (0) degrees before raising the boom. Raising the boom with an unlevel machine may cause the machine to overturn, resulting in injury or death.

# **WARNING**

Use the frame sway control to level the machine only when the boom angle indicator is at 0 degrees or less. Using the frame sway control when the angle indicator is more than 0 degrees may cause the machine to overturn, resulting in injury or death.

The frame sway control (A) is located on the forward side of the right arm rest. The frame sway control is used in conjunction with the machine level indicator (B) located in the center of the cross support that the interior rear view mirror is mounted on. The sway control switch is either toggled to the left or right depending on the particular requirement.






# **CONTROLS AND INSTRUMENTS**

#### GAUGES

The following gauges are used to monitor the machine:

- 1 Fuel Level
- 2 Water Temperature, Engine
- 3 Oil Pressure, Engine
- 4 Oil Temperature, Powershift Transmission
- 5 Oil Pressure, Powershift Transmission
- 6 Voltmeter



#### HYDRAULIC PUMP DESTROKE BUTTON




## DANGER

Depressing the pump destroke button while operating the machine will cause an immediate loss of hydraulic power, possibly creating a very dangerous situation. Hydraulic functions that will be affected are: FORK TILT, LIFT, BOOM EXTEND and RETRACT, PARKING BRAKE and SWAY. None of these functions will operate as long as the button is depressed. The service brakes will continue to function if the accumulator backup has a sufficient gas charge.

The pump destroke button (C) is the black push button switch located on the dash panel.

For example, when starting the machine for the first time on a 30 degree F. day, depress the pump destroke button while starting the engine. Continue to depress the button for 15 to 20 seconds after the engine starts. Once the engine is running smoothly, release the button and the hydraulic pump will engage. Depressing the pump destroke button will not be required for all other starts of the day, unless the engine has been allowed to cool completely.



# **CONTROLS AND INSTRUMENTS**

### STEERING

In addition to the steering wheel, the machine has another steering control, the steering selector switch.

The steering selector switch (A) is a three-position switch. The three positions are: 4-wheel, 2-wheel, and oblique. Switch positions are selected and function as follows:

4-WHEEL

Handle rotated forward

2-WHEEL

Handle directly centered


OBLIQUE (CRAB)

Handle rotated rearward



CAUTION

Before changing steering selections, make sure all four wheels are in line. Failure to align the wheels to the proper settings before changing steering positions may cause haphazard steering. This may result in injury to personnel and/or damage to the machine or property.



## TRANSMISSION

The transmission control (B) has one lever that controls both directional and speed requirements. It is located on the left side of the steering column.

To shift into Forward gear gently pull the lever toward you and move the lever upward.

To shift into Neutral move the lever to the center position.

To shift into Reverse gear gently pull the lever toward you and move the lever downward.

To shift into a lower speed rotate the lever clockwise.

To shift into a higher speed rotate the lever counter-clockwise.

When shifting the transmission from forward to reverse while the machine is in motion the transmission control (B) must be in 1st or 2nd gear only.

Forward/1st


Low speed/High torque

Forward/2nd

Medium speed/Medium torque

Forward/3rd

High speed/Low torque



# **CONTROLS AND INSTRUMENTS**

## FRONT AXLE DIFFERENTIAL LOCK

The front axle differential lock switch (C) is located near the operator's left foot. It is a standard feature on all TH842C & TH844C models. The purpose for this device is to lock the front axle differential to gain added traction under certain conditions.

The front axle differential lock switch must be depressed and held in order to activate the axle differential lock. Releasing the switch disengages the axle differential lock.

Use this differential lock when you are unable to drive through certain types of terrain such as sand, mud, snow, etc.


## / WARNING

Always bring the front tires to a complete stop before engaging the front axle differential lock.

Failure to stop the front tires before engaging the front axle differential lock may result in damage to the front axle.

Never steer the front tires while using the front axle differential lock.

Steering while the front axle differential lock is engaged may result in damage to the front axle.





# SECTION 4 OPERATION

## TABLE OF CONTENTS

## SECTION 4 - OPERATION

Operation And Safety Guidelines	4-3
Before Starting The Engine	4-4
Starting The Engine	4-9
Before Operating The Forklift	4-11
Transporting A Load	4-15
Placing A Load	4-17

#### OPERATION AND SAFETY GUIDELINES

## ⚠ WARNING


Your safety and the safety of those around you depends upon you using care and judgement in the operation of this equipment. Know the positions and functions of all controls before attempting to operate this machine. All equipment has limitations. Understand the speed, braking, steering, stability, and load chart characteristics of this machine before operating. Read the Operator's Manual and ask questions of your supervisor until you know the machine's limitations. It is very important to read, fully understand, and follow these operation and safety guidelines.

- DO NOT operate this machine while people are under or near an elevated boom whether the boom is loaded or unloaded.
   Falling objects from the forks or attachment may cause serious injury or death.
- ALWAYS remain completely within the cab enclosure while operating this machine. Falling debris can cause serious personal injury or death.
- 3. NEVER extend a load beyond the load chart band. Machine turn over, component damage, injury or death could occur.
- 4. ABSOLUTELY NO RIDERS SHOULD BE ALLOWED ON THIS MACHINE OR ATTACHMENTS.
- 5. NEVER lower a maximum load before retracting it. Machine turn over, component damage, injury or death could occur.
- INSPECT and clear the working area of any obstructions (rocks, fence, wire, etc.) that could cause machine damage. If obstructions cannot be cleared, mark the obstructions with a stake or other marker that will be clearly visible to the operator.
- DO NOT check the engine coolant level if the engine has recently been run. Injury could occur from escaping hot pressurized coolant.
- 8. ALWAYS wear the seat belt when operating this machine.
- ALWAYS inspect the machine daily. Check for leaks, worn hoses, loose belts, or anything out of the ordinary. Repair and/or replace any worn, damaged or leaking parts immediately. Failure to do so can cause injury or death.
- CHECK to be sure that all guards and screens are secure and in their proper place.
- CHECK to be sure that all safety devices such as parking brake, service brake, level gauge, neutral start safety switch, back-up alarm, and horn are functioning properly. Always make sure mirror is adjusted properly.
- 12. DO NOT travel on terrain or in dangerous areas that could cause the machine to tip over.
- 13. DO NOT attempt to start the engine by towing or pushing. Damage to the powershift transmission could result.
- 14. CARRY A LOAD so that you have maximum machine stability and visibility is not obstructed.
- ALWAYS level the machine as indicated on the machine level indicator before raising boom. Raising the boom with an
  unlevel machine may cause the machine to overturn causing injury or death.
- 16. USE the frame sway control to level the machine only when the boom position is horizontal or lower. Using the frame sway control when the boom is higher than a horizontal position may cause the machine to overturn causing injury or death.
- 17. DO NOT depress the pump destroke button while operating the machine. This button should be used <u>only</u> during cold start ups. Depressing the button while operating the machine will cause an immediate loss of hydraulic power that will affect fork tilt, lift, boom extend and retract, sway and all other hydraulic functions. Brakes will continue to function if the accumulator backup has a sufficient gas charge.

## BEFORE STARTING THE ENGINE

## **WARNING**

DO NOT perform any procedures in this section, "BEFORE STARTING ENGINE", unless the machine's engine is turned off and the parking brake is applied and the engine is cool. Failure to do so may result in serious injury, death or damage to the equipment.



Walk around the machine and check for any parts that are missing, worn, damaged, or leaking. Repair and/or replace damaged parts.

#### CHECK ENGINE OIL LEVEL

Location: Dipstick (A).

To Check: The machine must be level.

Check when the engine is cold.

Remove the dipstick from the engine.


Oil should read between the add and the

full marks.

Replace the dipstick.

NOTE: Refer to page 5-24 of this manual for the proper oil specifications and capacities.

#### John Deere



## BEFORE STARTING THE ENGINE

## **WARNING**

DO NOT check the coolant level if the engine has been run recently. Injury may occur from hot escaping pressurized coolant.


#### CHECK ENGINE COOLANT LEVEL

Location: Tank cap (B).

To Check: Coolant should be visible in the top of the tank.

NOTE: If coolant needs to be added, fill with a 50/50 low silicate antifreeze mix (-34 degrees F) with an approved nitrite or nitrite-molybdate based Supplemental Coolant Additive. This additive is required to prevent engine damage due to cylinder liner erosion and pitting. Do not use high-silicate automotive antifreeze or cooling system damage due to silicate dropout can occur.

Contact your local John Deere dealer for an approved antifreeze and Supplemental Coolant Additive.



#### OPEN WATER SEPARATOR

Location: Water separator filter (C).

To Open: Shut off the engine.

Turn the valve on the bottom of the water separator filter counterclockwise.


Drain until clear fuel is present.

Retighten the valve.

NOTE: If more than 2 oz. of fuel are drained, refilling of the filter is required to prevent hard starting. Refer to filter

replacement on page 5-19 of this manual.

#### John Deere



## BEFORE STARTING THE ENGINE

#### CHECK HYDRAULIC OIL LEVEL

Location: Sight glass (A). Behind the rear panel.

To Check: Move the machine to level ground.

Level the frame.

Completely retract the boom.


Position the forks level.

Lower the boom to the ground.

Oil should be visible 1/2 way in the sight glass.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



#### INSPECT AIR CLEANER

Location:

Air cleaner assembly.

To Check:

Remove the rear of the canister, remove the

elements.


Guideline:

Inspect the filter elements for contamination. Inspect the tubing going to the filter body from the engine for cracks or leaks. Inspect the air cleaner body and gaskets for cracks

or leaks.



Due to various operating conditions, the air cleaner's elements should be changed as often as the environment requires.



## BEFORE STARTING THE ENGINE

#### CHECK TRANSMISSION OIL LEVEL

Location: Dipstick (B)

To Check: Level the machine.

Place the transmission control in neutral.

Set the parking brake.

The engine must be running to check.


Bring the transmission oil temperature to a minimum of 180 degrees F.


Remove the dipstick. The oil level should be between the add and full marks.

Replace the dipstick.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.





## BEFORE STARTING THE ENGINE

#### CHECK TIRE FOR PROPER INFLATION

Location: Wheel ends.

To Check: Check the tire pressure with the tire cold and a


properly functioning air pressure gauge. Position

the valve stem (A) to the top of the tire.

Setting: 50 PSI.



All tires require a calcium chloride ballast or an optional foam filling to be operated safely. The loss of ballast can affect machine stability and cause a rollover hazard resulting in damage, injury or death.



## STARTING THE ENGINE

## **A** DANGER

Any problems discovered in the steps prior to "BEFORE STARTING THE ENGINE" should be corrected before the machine is started.


# A DANGER

NEVER attempt to start the machine without being seated in the operator's compartment, the parking brake switch (B) toggled forward in the on position and the transmission control (C) in the neutral position. Attempting to start the machine from outside the operator's compartment may result in property damage, serious injury or death.

# A DANGER

If the machine should start with the transmission control lever (C) in gear, stop operation at once or property damage, serious injury or death may occur. Have a qualified service technician repair the machine.

Insert the ignition key in the ignition switch (D). Rotate the key clockwise until the engine starts. Release the key when the engine starts.




## STARTING THE ENGINE

# **A**CAUTION

If the engine fails to start within 30 seconds release the key, wait at least 2 minutes to allow the starter motor to cool before trying again. If the engine fails to start after four attempts, trouble shoot and correct the problem. DO NOT turn the key if the engine is running. This may cause damage to the starter motor.

## **A**CAUTION

Attempting to start the engine by towing or pushing the machine will result in damage to the powershift transmission and will not start the engine! It also is an unsafe practice that could cause personal injury.



### BEFORE OPERATING THE FORKLIFT

## A CAUTION

If any gauge reading does not fall within the set tolerances the machine must be repaired before operation.

Check the dash mounted gauges for logical readings.

(1) Fuel Level 1/2 to Full


(2) Engine Water Temperature 180°F to 200°F

(3) Engine Oil Pressure 40 to 80 PSI


(4) Transmission Oil Temperature 180°F to 200°F


(5) Transmission Oil Pressure 240 to 280 PSI


(6) Voltmeter 12 to 14 Volts



Operate the joystick controller momentarily in all directions.









## BEFORE OPERATING THE FORKLIFT

Operate the frame sway control (A) momentarily right and left.



Check the steering operation by turning the steering wheel (B) approximately 1/4 turn in each direction. If the front and rear tires are not aligned properly, straighten the rear wheels with the steering selector valve (C) in the "4 wheel" position. Move the steering selector valve to the "2 wheel" position. Bring the front tires into alignment with the rear tires. Place the steering selector valve back into the "4 wheel" position.




#### BEFORE OPERATING THE FORKLIFT


## 1 DANGER

Any problems with the service brakes or the parking brake found while conducting the daily inspection should be corrected immediately. Failure to do so could result in injury or death.

Activate the transmission using the transmission control lever (D). As soon as the machine starts to move, apply the service brake pedal. The machine should stop immediately.



Apply the parking brake by toggling the parking brake switch (E) forward. The red light in the upper part of the parking brake switch should illuminate. The machine should not be able to be driven with the parking brake in the forward / on position. Release the parking brake by toggling the parking brake switch rearward.




## BEFORE OPERATING THE FORKLIFT




Never operate the machine with a faulty backup alarm. Doing so may result in serious injury or death.

Place the transmission control lever (A) in reverse. The backup alarm should sound. If it does not sound, have the backup alarm repaired immediately.



Check and adjust both the interior rear view mirror (B) and the exterior right hand mirror (C) if required.



## TRANSPORTING A LOAD


## **WARNING**

Transporting a load with the boom extended and the boom angle indicator arrow (D) reading more than 0 degrees could cause a roll over hazard.


# **A** WARNING

At no time should any load be suspended from the forks by use of chains, ropes, straps etc. If a load must be suspended the use of a truss (jib) boom is mandatory. Proper rigging procedures should always be followed.

The forks should always be tilted back slightly during transportation to ensure stability of the load.




The load should be kept as low to the ground as possible while traveling. Always move a loaded machine with the boom angle indicator (D) at 0 degrees or less.




#### TRANSPORTING A LOAD

## **WARNING**


Slower speeds should be used whenever transporting a load. Always bring the machine to a complete stop before reversing the transmission control lever (A). Failure to do so can result in damage to the load, the machine and/or bystanders.



Always keep the boom retracted to ensure greater stability.



Always place the load in the center and completely against the back of the fork frame. By doing so greater stability will result.



IMPORTANT: Never attempt to use the forks and/or attachments for prying wedged or frozen loads free. Damage to the load, pallet and/or machine could result.

## PLACING A LOAD



## WARNING

Do not sway the machine with the boom angle indicator arrow (B) at more than 0 degrees. By doing so you could cause a roll over hazard which may result in injury or death.




## DANGER

Always apply the parking brake by toggling the parking brake switch (C) forward before lifting and/or placing a load. Failure to do so could allow the machine to roll over which may result in injury or death.



## CAUTION

Always bring the machine to a complete stop before applying the parking brake (C). Failure to do so will damage the parking brake disc packs, which may void the axle warranty.








Always ensure that the machine level indicator (E) is at zero (0) degrees before raising the boom. Raising the boom with an unlevel machine may cause the machine to overturn, resulting in injury or death.




Use the frame sway control to level the machine only when the boom angle indicator (B) is at 0 degrees or less. Using the frame sway control when the angle indicator is more than 0 degrees may cause the machine to overturn, resulting in injury or death.










## PLACING A LOAD

## **!** DANGER


Traveling with a reading of more than 0 degress on the boom angle indicator arrow (A) may cause a rollover hazard.



Gradually move the 4-way controller towards the letter (B) to lift the load vertically. Hold the controller back until the required height has been achieved.

Gradually move the 4-way controller towards the letter (E) to bring the load DOWN and OUT into final position. Lower the load until the weight is completely off the forks.


Gradually move the 4-way controller towards the letter (F) to bring the boom UP and IN. This will bring the forks out of the load. Once the forks are clear of the load the boom can be lowered.



## PLACING A LOAD

## TH644C, TH842C, TH844C

When placing a load with the Model TH644C, TH842C, or the TH844C the rear axle stabilizing cylinders need to be taken into consideration. When the boom reaches an angle of 60 DEGREES, all frame leveling and transmission functions are disabled and the rear axle stabilizing cylinders become locked. This DOES NOT affect any boom or fork functions. To unlock the rear axle stabilizing cylinders and enable the transmission functions, lower the boom to a position less than 60 degrees.





# SECTION 5 MAINTENANCE PROCEDURES

## TABLE OF CONTENTS

## SECTION 5 - MAINTENANCE PROCEDURES

Service Intervals	5-5
Required Grease Intervals	5-6
Grease Fitting Locations	5-7
Daily Maintenance Procedures	5-8
50 Hour Maintenance Procedures	5-12
100 Hour Maintenance Procedures	5-15
250 Hour Maintenance Procedures	5-17
500 Hour Maintenance Procedures	5-18
750 Hour Maintenance Procedures	5-20
1000 Hour Maintenance Procedures	5-21
2000 Hour Maintenance Procedures	5-23
Filter Guide	5-24
Recommended Fluids And Capacities	5-24
Hydraulic Pressure Settings	5-25

## GENERAL SAFETY PRACTICES

#### BEFORE SERVICING

Read the entire Maintenance Procedure Section.

Familiarize yourself with all the safety precautions listed in Sections 1 & 2.

Pay close attention to all the safety alert symbols.

Be sure you understand the procedures detailed in this section.

Wear personal protective equipment.

Remove rings and jewelry.

Move the machine to a safe level work place.

Lower the boom and support all raised equipment.

Shut down the machine.

Remove the key from the ignition.

Be careful not to spill fuels and lubricants.

Do not fill or refuel the fuel tank while the engine is running or hot. Doing so could cause a fire and/or an explosion.

Do not smoke while refueling or working with fuel to avoid a fire and/or explosion.

IMPORTANT! Always clean up spilled fuel and/or lubricants to avoid polluting the earth.

## GENERAL SAFETY PRACTICES


#### HYDRAULIC SAFETY

# **WARNING**

Hot hydraulic oil can cause severe burns. **DO NOT** work on the hydraulic system if the oil system temperature exceeds 120 degrees F. (49 degrees C.)

Before ANYONE works on the hydraulic system:

- 1. Lower the boom to the horizontal position.
- 2. Support the boom to avoid unintentional lowering.
- 3. Shutdown the engine.
- 4. Remove the key from the ignition.
- Clean the area around the oil reservoir cap (A).




#### FLUID UNDER PRESSURE



Escaping fluid under pressure can penetrate the skin and can cause serious personal injury.

Use a piece of cardboard or paper to search for leaks. **DO NOT** use hands! Before disconnecting hydraulic lines, be sure to relieve all line pressure. Before applying pressure to the system, be sure that all connections are tight. **DO NOT** apply pressure to a damaged line, hose or fitting.

If injured by escaping fluid, see a doctor at once. Proper medical treatment must be administered immediately. A serious infection or reaction can result without proper medical treatment.



#### WELDING PRECAUTIONS

# **!** WARNING

**DO NOT** weld on any structural member. Any unauthorized welding can cause structural failure or possible personal injury. All unauthorized welding or repair procedures will void the machine warranty.

Before performing any authorized welding, be sure to disconnect the positive lead from the battery. Properly attach the ground cable of the welder to the frame member that is being welded. Failure to do so can cause electrical system damage.



## SERVICE INTERVALS

	DAILY	50 Hrs.	100 Hrs.	250 Hrs.	500 Hrs.	750 Hrs.	1000 Hrs.	2000 Hrs.
CHECK ENGINE OIL	•	XIII WANTAN						
CHECKENGENEOIL	_							
CHECK COOLANT LEVEL	•	4						
CHANGE HYDRAULIC RETURN FILTER ELEMENT		•*		•				
CHANGE ENGINE OIL & FILTER			•*		•			
INSPECT ALTERNATOR BELT							•	
ENGINE VALVE ADJUSTMENT	1000						•	•* * *
CHANGE DIFFERENTIAL OIL (AXLE)			•*			•	00112	
REPLACE FUEL FILTERS					•			
COOLANT CONCENTRATION					•			
CHECK ENGINE FAN	•							
OPEN WATER SEPERATOR	•							
CHECK TIRE INFLATION	•							
FLUSH AND PRESSURE TEST COOLING SYSTEM								•
CHECK TRANSMISSION OIL	•							
REPLACE TRANSMISSION OIL & FILTER		•*	•**		•			
CHECK AXLE OIL LEVELS		•						
CHANGE PLANETARY REDUCTION OIL (AXLE)			•*			•		
INSPECT AIR CLEANER AND AIR CLEANER SYSTEM	•							311-4
CHECK HYDRAULIC OIL LEVEL	•							
CHECK HYDRAULIC RETURN FILTER ELEMENT	•							

For procedures to perform the above listed items turn to the following pages: 5-8 thru 5-23.


- \* For initial break-in period only.
- \*\* For initial 100 hours only.
- \*\*\* John Deere engines require valve adjustment every 2000 hours only.

# REQUIRED GREASE INTERVALS

LOCATION	DAILY	50 Hrs.	250 Hrs	500 Hrs.
SMALL BOOM ROLLERS (4)		•		
BASE END TILT CYLINDER		•		
HEAD END TILT CYLINDER	•			
FORK FRAME PIVOT PIN (2)	•			
HEAD END LIFT CYLINDER (2)	•			
BASE END LIFT CYLINDER (2)	•			
FRONT DRIVESHAFT (3)			•	
REAR DRIVESHAFT (3)			•	
BASE END SWAY CYLINDER (2)	•			
HEAD END SWAY CYLINDER (2)	•			
BOOM PIVOT (2)	•			
REAR AXLE TRUNIONS (4)		•		
FRONT AXLE TRUNIONS (4)		•		
FRONT AXLE PIVOT (2)		•		
REAR AXLE PIVOT (2)		•		
MIDDLE BOOM ROLLERS (4)		•		
BASE END REAR LOCK UP CYLINDER (2)	•			
HEAD END REAR LOCK UP CYLINDER (2)	•			

## GREASE FITTING LOCATIONS

## TH644C & TH842C & TH844C



#### DAILY MAINTENANCE

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

#### CHECK ENGINE OIL LEVEL

Location:

Dipstick (A).

To Check:

The machine must be level.

Check when the engine is cold.

Remove the dipstick from the engine.

The oil level should be between the add


and full marks.

Replace the dipstick.

NOTE:

Refer to page 5-24 of this manual for the proper oil specifications and capacities.

#### John Deere



## **!** WARNING

Do not check the coolant level if the engine has recently been run. Injury may occur from hot escaping pressurized coolant.

#### CHECK ENGINE COOLANT LEVEL

Location:

Radiator cap (B).


To Check:

Coolant should be visible in the top of the tank.

NOTE:

If coolant needs to be added, fill with a 50/50 low silicate antifreeze mix (-34 degrees F) with an approved nitrite or nitrite-molybdate based Supplemental Coolant Additive. This additive is required to prevent engine damage due to cylinder liner erosion and pitting. Do not use high-silicate automotive antifreeze or cooling system damage due to silicate dropout can occur.

Contact your local John Deere dealer for an approved antifreeze and Supplemental Coolant Additive.



## DAILY MAINTENANCE


# **WARNING**

Serious personal injury can result from a loose or damaged fan. Never pry on a fan because this may cause fan damage and/or failure.

#### CHECK ENGINE FAN

To Check: Visually inspect the cooling fan (C) for cracks,

loose bolts, bent or loose blades, etc.



#### OPEN WATER SEPARATOR

Location: Water separator filter (D).

To Open: Shut off the engine.

Turn the valve on the bottom of the filter

counterclockwise.

Drain until clear fuel is present.


Retighten the valve.

NOTE: If more than 2 oz. of fuel are drained, refilling of the

filter is required to prevent hard starting. Refer to filter

replacement on page 5-19 of this manual.

#### John Deere



## DAILY MAINTENANCE

#### CHECK TRANSMISSION OIL LEVEL

Location: Dipstick (A)

To Check: Level the machine.

Place the transmission control in neutral.

Set the parking brake.

The engine must be running to check.


Bring the transmission oil temperature to a minimum of 180 degrees F.

Remove the dipstick. The oil level should be between the add and full marks.

Replace the dipstick.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



#### CHECK HYDRAULIC OIL LEVEL

Location: Sight glass (B). Behind the rear panel.

To Check: Move the machine to level ground.

Level the frame.

Completely retract the boom.


Position the forks level.

Lower the boom to the ground.

Oil should be visible 1/2 way in sight glass (B).

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



## DAILY MAINTENANCE

#### CHECK TIRE FOR PROPER INFLATION

Location: Wheel ends.


To Check: With the valve stem (C) positioned to the top of

the tire, check the tire pressure with the tire cold and a properly functioning air pressure gauge.

Setting: 50 PSI.



All tires require a calcium chloride ballast or an optional foam fill to be operated safely. The loss of ballast can affect the machine's stability and cause a rollover hazard, resulting in damage, injury or death.



#### INSPECT AIR CLEANER

Location: Air cleaner assembly.

To Check: Remove the rear of the canister, remove

the filter elements.


Guideline: Inspect the filter elements for contamination.

Inspect the tubing going to the filter body from the engine for cracks or leaks. Inspect the air cleaner body and gaskets for cracks

or leaks.



Due to various operating conditions, the air cleaner's elements should be changed as the environment requires.



## **50 HOUR MAINTENANCE**

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

#### CHECK HYDRAULIC RETURN FILTER GAUGE

Location: Return filter gauge (A). Located behind the left hand

side screen, on top of the oil reservoir and on the left hand side of the return filter assembly (B).

To Check: Raise the boom to the horizontal position.

Extend the boom cylinder fully.

Raise the engine speed to full RPM.

Retract the boom cylinder at full speed.

The return filter gauge reading should not read more than 25 PSI. If the reading is more than 25 PSI, the filter element must be changed.

#### CHANGE HYDRAULIC RETURN FILTER ELEMENT

Location: The return filter element (C) is located inside the

return filter assembly (B) on top of the oil reservoir.

To Change: Retract the boom and lower the forks to the ground. Shut off the engine. Release the pressure in the oil

reservoir by loosening the filler / breather cap (D).

## **A** CAUTION


The return filter assembly cover is spring loaded.

Loosen, but do not remove, the four cover bolts (E) on the top of the return filter assembly. Carefully push down and rotate the cover clockwise to remove. Remove the cover spring and pull the filter element out using the swivel handle on the element. Make sure both o-rings are in place inside the new filter element, then transfer the bypass valve (F) into the new filter element. Reinstall the filter element, cover spring and cover, making sure the o-ring is in place between the cover and the return filter assembly.

NOTE: This change interval is only for the first initial 50 hours of

use. Following initial replacement of filter see Service Intervals on page 5-5 of this manual for standard change

intervais



## **50 HOUR MAINTENANCE**

#### CHANGE TRANSMISSION OIL AND FILTER

Location:

Transmission filter (G).

Drain plug (H). Dipstick (I).

To Change:

Bring the transmission oil temperature to a

minimum of 180 degrees F.

Remove the drain plug.

Allow the oil to drain completely into a

proper collection container.

Clean the area around the filter thoroughly.

Remove the transmission filter.

Apply a thin film of clean transmission oil to the new filter gasket surface and install the filter according to the manufacturer's

specifications.

Install the drain plug.

Fill the transmission through the dipstick tube (I) until the oil level is between the add

and full marks.

Run the engine for a minimum of 2 minutes

at engine idle.

Check the oil level at the dipstick.

Raise the transmission oil temperature to a minimum of 180 degrees F. Recheck the oil at

the dipstick.

NOTE:

This change interval is only for the first initial 50


hours of use. Following the initial replacement of oil and filter see the Service Intervals on page 5-5 of this manual

for the standard change interval.

NOTE:

Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



## **50 HOUR MAINTENANCE**

#### CHECK AXLE PLANETARY OIL

Location: Filler/drain plug (A).

To Check: Always check the lubricant level in the wheel end

with the filler/drain plug at the 3 or 9 o'clock

position.


Remove the filler/drain plug.

Oil should flow freely from the hole.

Replace the filler/drain plug.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



#### CHECK AXLE DIFFERENTIAL OIL

Location: Fill plug (B).

Check plug (D). Drain plug (C).

To Check: Move the machine to level ground.


Remove the check plug. Oil should flow freely

from the hole.

Replace the check plug.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



## 100 HOUR MAINTENANCE

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Complete all "50 HOUR MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

#### CHANGE AXLE DIFFERENTIAL OIL

Location:

Fill plug (B).

Check plug (D).

Drain plug (C).

To Change: Remove the drain plug.

Loosen the fill plug to allow the oil to drain completely into a proper collection container.

Replace the drain plug.

Remove the check plug and the fill plug.

Fill with oil through the fill plug hole until it flows freely from the check plug hole.


Replace the check plug and the fill plug.

NOTE: This time interval is for the first initial 100 hours. Refer to

page 5-5 of this manual for additional service intervals.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



## 100 HOUR MAINTENANCE

#### CHANGE AXLE PLANETARY END OIL

Location: Filler/drain plug (A).

To Change: Rotate the wheel end until the filler/drain plug

is at the lowest point of the wheel end.

Remove the filler/drain plug and allow the oil to drain completely into a proper collection

container.

Rotate the wheel end until the filler/drain plug hole is at the 3 or 9 o'clock position.

Fill with oil until it flows freely from the filler/ drain plug hole.


Replace the filler/drain plug (A).

NOTE: This time interval is for the first initial 100 hours. Refer to

page 5-5 of this manual for additional service intervals.

NOTE: Refer to page 5-24 of this manual for the proper oil

specifications and capacities.



#### CHANGE TRANSMISSION OIL AND FILTER

To Change: Refer to the procedure listed on page 5-13 of this

manual.

NOTE: This time interval is for the first initial 100 hours. Refer to

page 5-5 of this manual for additional service intervals.

## 250 HOUR MAINTENANCE


Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Complete all "50 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "100 HOUR MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.



#### CHANGE HYDRAULIC RETURN FILTER ELEMENT

Location:

The return filter element (C) is located inside the return filter assembly (B) on top of the oil reservoir.

To Change: Retract the boom and lower the forks to the ground. Shut off the engine. Release the pressure in the oil reservoir by loosening the filler / breather cap (D).



The return filter assembly cover is spring loaded. Loosen, but do not remove, the four cover bolts (E) on the top of the return filter assembly. Carefully push down and rotate the cover clockwise to remove. Remove the cover spring and pull the filter element out using the swivel handle on the element. Make sure both o-rings are in place inside the new filter element, then transfer the bypass valve (F) into the new filter element. Reinstall the filter element, cover spring and cover, making sure the o-ring is in place between the cover and the return filter assembly.



## **500 HOUR MAINTENANCE**

#### CHANGE ENGINE OIL AND FILTER

Location:

Oil filter (A).

Drain plug (B).

Fill cap (C).

To Change: Operate the engine until the engine water

temperature has reached 140 degrees F.

Turn the engine off.

Remove the drain plug (B).

Allow the oil to drain completely into a proper collection container.

Clean the area thoroughly around the filter area. Remove the engine oil filter.

Apply a thin film of clean engine oil to the new oil filter gasket surface.

Fill the oil filter with clean engine oil before installation.

Install the oil filter to the manufacturer's specifications.

Clean the surface around the drain plug.

Install the drain plug.

Fill the engine with the proper oil through the oil fill cap until the oil level is between the add and the full marks on the dipstick.

Run the engine for a minimum of 2 minutes at engine idle.


Turn the engine off.

Once the engine has cooled recheck the oil level at the dipstick.

NOTE:

Refer to page 5-24 of this manual for the proper oil specifications and capacities.





## 500 HOUR MAINTENANCE

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Complete all "50 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "100 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "250 HOUR MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

#### REPLACE FUEL FILTERS

Location:

Filter (D).

Water separator (E).

To Change: Wipe all the dirt from the area surrounding

the filter(s).

Remove the filter(s). Thoroughly clean the gasket

sealing surface after filter removal.

Fill the new filter(s) with fuel.


Install the new filter(s).

Install the filter(s) according to the filter

manufacturer's specifications.

NOTE: John Deere engines only have one filter element. It is used as a

filter and water separator.



## 500 HOUR MAINTENANCE

#### CHECK COOLANT CONCENTRATION

Location:


Radiator cap (A).

To Check:

Remove the radiator cap.

Factory recommended coolant concentration is a 50/50 mixture of low silicate antifreeze (-34 degrees F.) with an approved nitrite or nitrite-molybdate based Supplemental Coolant Additive. This additive is required to prevent engine damage due to cylinder liner erosion and pitting. Do not use high-silicate automotive antifreeze or cooling system damage due to silicate dropout can occur.

Contact your local John Deere dealer for an approved antifreeze and Supplemental Coolant Additive.



#### 750 HOUR MAINTENANCE

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Complete all "50 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "100 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "250 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "500 HOUR MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

#### CHANGE AXLE OILS

**To Change:** Refer to the procedures listed on pages 5-15 & 5-16 of this manual.

## 1000 HOUR MAINTENANCE

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Complete all "50 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "100 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "250 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "500 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "750 HOUR MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

MANUFACTURER ENGINE MANUALS ARE AVAILABLE FROM YOUR LOCAL TEREX HANDLER DEALER.

#### ADJUST ENGINE VALVES

To Adjust: See engine manual for procedure.

#### CHECK FAN BELT TENSION

To Check: See engine manual for procedure.

#### CHECK FAN BELT CONDITION

To Check: See engine manual for procedure.

#### CHANGE TRANSMISSION OIL AND FILTER

To Change: Refer to procedure listed on page 5-13 of this

manual.

## 1000 HOUR MAINTENANCE

#### ADJUST EXTENSION - RETRACTION CHAINS

TO CHECK: Raise the boom to the horizontal position. The proper adjustment can be checked with a tape measure. Extend the boom fully, then retract the boom about one inch. On either side of the middle boom section estimate the center. Place one end of the tape measure on the top surface of the boom directly above the estimated center.


**TOLERANCE:** The measurement from the top surface of the boom to the lowest part of the extension chain should be no less than 2 3/8 inches.


TO ADJUST: If the measurement is less than 2 3/8 inches, tighten the chain anchor (A), which is located on the top, front of the large boom tube, as follows:

A. Tighten an adjustable wrench across the flat part of the chain just ahead of the chain anchor (A).

B. With a 1 7/16 inch wrench tighten the one inch nut to collapse the spring. Continue to tighten until the chain is in tolerance.

C. With a feeler gauge check the gap between the spring (B). The gap should be no less than .030. The spring coils should never be collapsed completely.





## 2000 HOUR MAINTENANCE

Perform "BEFORE SERVICING PROCEDURES" before attempting any of the following checks.

Complete all "DAILY MAINTENANCE" checks prior to this time interval.

Complete all "50 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "100 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "250 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "500 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "750 HOUR MAINTENANCE" checks prior to this time interval.

Complete all "1000 HOUR MAINTENANCE" checks prior to this time interval.

Perform "BEFORE OPERATING CHECKS" before attempting any of the following checks.

## FLUSH AND PRESSURE TEST COOLING SYSTEM

To Test: See engine manual for procedure.

# FILTER GUIDE

FILTER	PART NO.
Engine Oil Filter / John Deere	7-183-184
Transmission Oil Filter	7-126-349
Hydraulic Oil Reservoir Return Filter Element	7-118-02
Engine Air Cleaner Element / Primary	7-109-04
Engine Air Cleaner Element / Safety	7-109-14
Engine Fuel Filter / John Deere	7-183-45
Filler-Breather (Hydraulic Oil Reservoir)	7-272-11

## RECOMMENDED FLUIDS AND CAPACITIES

DESCRIPTION	<b>CAPACITY</b>	<u>TYPE</u>
Engine Oil / John Deere	14 Quarts	Refer to John Deere engine manual
Transmission Oil	13.6 Quarts	Chevron RPM SAE 10W
Axles		
Differential	9 Quarts	Chevron Supreme 80W90 LS
Planet Ends	1 Quart (Each End)	Chevron Supreme 80W90 LS
Hydraulic Oil Reservoir	34 Gallons	Chevron AW 46
Hydraulic System	50 Gallons	Chevron AW 46
Fuel Tank	30 Gallons	# 2 Diesel Fuel

NOTE: Fluid levels may vary slightly from machine to machine so fluid levels should always be checked manually.

## HYDRAULIC PRESSURE SETTINGS

#### GAUGE PORT 1 (G1) MAIN PUMP PRESSURE


Location: Test port 1 (A). Behind the right hand rear side screen. Hydraulic pump (B). Under the transmission cover.

Adjuster (C). On the hydraulic pump.

To Check: Attach a pressure gauge to test port 1 (A). Start the engine. Do not operate any controls. The pressure reading should be as follows:

TH644C	3000 PSI
TH842C	3000 PSI
TH844C	3000 PSI

To Adjust: Remove the acorn nut from the adjuster (C). Loosen the jam nut and turn the allen head adjusting screw clockwise to increase the pressure and counterclockwise to decrease the pressure. Retighten the jam nut. Replace the acorn nut.



### GAUGE PORT 1 (G1) SERVICE BRAKE ACCUMULATOR


Location: Test port 1 (A). Behind the right hand rear side screen.

To Check: Attach a pressure gauge to test port 1 (A). Start the engine. Do not operate any controls. Apply and release the service brakes a few times. With the service brakes released, shut down the engine. The pressure reading should be as follows:

TH644C	3000 PSI
TH842C	3000 PSI
TH844C	3000 PSI

To Adjust: Not adjustable. If the pressure drops below 2000

PSI after a period of two minutes, troubleshoot the brake circuit.



## HYDRAULIC PRESSURE SETTINGS

#### GAUGE PORT 2 (G2) STEERING SYSTEM PRESSURE

Location: Test port 2 (A). Behind the right hand rear side screen.


Control block (B). On the front face of the oil reservoir.

Cartridge (C). On the control block.

To Check: Attach a pressure gauge to test port 2 (A). Start the engine. Do not operate any controls. The pressure reading should be as follows:

TH644C	2250 PSI	
TH842C	2250 PSI	
TH844C	2250 PSI	

To Adjust: Loosen the jam nut on the steering cartridge
(C) and turn the allen head adjusting screw
clockwise to increase the pressure and
counterclockwise to decrease the pressure.
Retighten the jam nut.




## GAUGE PORT 3 (G3) CONTROL (PILOT) PRESSURE

Location: Test port 3 (D). Behind the right hand rear side screen. Control block (B). On the front face of the oil reservoir. Cartridge (E). On the control block.

To Check: Attach a pressure gauge to test port 3 (D). Start the engine. Do not operate any controls. The pressure reading should be as follows:

TH644C	500 PSI
TH842C	500 PSI
TH844C	500 PSI

To Adjust: Loosen the jam nut on the controller cartridge (E) and turn the allen head adjusting screw clockwise to increase the pressure and counterclockwise to decrease the pressure. Retighten the jam nut.



## HYDRAULIC PRESSURE SETTINGS

#### GAUGE PORT 4 (G4) TILT LIMITER PRESSURE

Location: Test port 4 (F). Behind the right hand rear side screen.


Tilt Limiter Block (H). On the front of the oil reservoir.

Cartridge (I). On the Tilt Limiter Block.

To Check: Attach a pressure gauge to test port 4 (F). Start the engine. Completely collapse the fork tilt cylinder and hold in a dead head position. (The tilt cylinder must be collapsed completely and dead headed to get a pressure reading). The pressure reading should be as follows:

TH644C	1200 PSI
TH842C	1200 PSI
TH844C	1200 PSI

To Adjust: Loosen the jam nut on the tilt limiter cartridge (I) and turn the allen head adjusting screw clockwise to increase the pressure and counterclockwise to decrease the pressure. Retighten the jam nut.





# SECTION 6 MATERIAL SAFETY DATA

# TABLE OF CONTENTS

# SECTION 6 - MATERIAL SAFETY DATA

Material Safety Data Sheets	6-3
California Proposition 65 Warnings	6-4

#### MATERIAL SAFETT DATA

## MATERIAL SAFETY DATA SHEETS (MSDS)

The Federal Occupational, Safety and Health Administration (OSHA) Standard 29 ctr 1910.1200, and in some cases state and local Right-To-Know laws, may require specific MSDS be available to employees prior to operating this equipment. This may include information on substances contained in the equipment such as antifreeze, brake fluid, battery acid and hydraulic fluid.

TEREX HANDLERS will provide, at no cost, Material Safety Data Sheets which are applicable to their product line. Simply request them from your local TEREX HANDLER dealer or contact us at:

TEREX HANDLERS P.O. Box 790 Baraga, MI 49908-0790

To ensure a prompt response, please be sure to include your return address and zip code, along with the machine model and serial number.

#### MATERIAL SAFETT DATA

## CALIFORNIA PROPOSITION 65 WARNINGS

The following warnings are required on all off road equipment operating in the State of California. If you are operating a TEREX HANDLER in the State of California and do not see the approved warning labels, please contact us for a replacement at no charge. Our address is:

TEREX HANDLERS P.O. Box 790 Baraga, MI 49908-0790

## CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

## CALIFORNIA Proposition 65 Warning

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.

Batteries also contain other chemicals known to the State of California to cause cancer.

Wash hands after handling.



